


How to remove battery from light source


Do

To remove the battery, grasp its front section and gently lift upwards until fully disconnected.




Don't


Do not attempt to remove the battery by simultaneously twisting and pulling upward.



How to remove light source from loupes



Hold the loupes and light as shown in the image, pinch up the light source with your thumb.



To prevent any damage, carefully detach the light source from the loupes.